

Tool Needed: 5mm Hex Key

kuat

1. Remove the two 8mm bolts and remove rub pad.

