

Tools Needed: 2.5mm Hex Key and 5mm Hex Key

..kuat..[®]
(koo-at)

NOTE: 2-Bike Transfer with driver side disassembly shown below, disassembly is equivalent for passenger side and all Transfer series racks.

1. Rotate the rack into the trailer position as shown below.

NOTE: Ensure the pivot latch bar has fully engaged the pivot bracket before proceeding.

2. Remove the m4 bolt and m6 bolts retaining the end cap, tire cradle with puck, and hinge.

TIP: Make a note of the tire cradle position to maintain bike position after reinstalling.

3. Remove the end cap, tire cradle with puck, and hinge.

4. Remove the two m6 bolts retaining the hinge puck and remove the hinge puck.

5. Remove the m6 bolt retaining the front tire cradle and remove the cradle with its puck.

TIP: Make a note of the tire cradle position to maintain bike position after reinstalling.

6. Install the new front tire cradle and puck with the provided hardware, making sure not to overtighten the m6 bolt.

7. Install the remaining components in the reverse order of removal, making sure not to overtighten the remaining hardware.

