

Tools Needed: T10 Torx Key

1. Using the T10 Torx Key, remove the two screws from the side of the rear cap and pull out slowly. Note: Wires are attached to the rear of the cap.
2. Pull apart connector at the base of the cap.
3. Repeat these steps in reverse to install the new one.

