

Tool Needed: 5mm Hex Key

kuat[®]

1. Using the 5mm Hex Key, remove the tire tray end cap.
2. Lift up to remove the end cap filler
3. Repeat these steps in reverse to install the new one.

