

Tools Needed: 6mm Hex Key, 8mm Hex Key

1. Using the 8mm Hex Key, remove the trays.
2. Using the 6mm Hex Key, remove the connector cap.
3. Repeat these steps in reverse to install the new one.

kuat®

