

Tools Needed: 4mm Hex Key, 6mm Ball-End Hex Key,
6mm Ball End Impact Bit (optional)

1. Using the 4mm Hex Key, remove (2x) 5mm bolts that secure the cover and remove cover.
2. Repeat step 1 for all 4 corners.
3. Remove (4x) 8mm bolts by one of two methods:
 - a. Use 6mm Ball-End hex key
 - b. Use 6mm Ball-End Impact Bit (extra tools required).
4. Repeat step 3 on other side to remove vertical components.
5. Connect corners with (2x) 8mm bolts and (2x) 8mm hex nuts.
6. Repeat step 5 on other side and reinstall covers to complete assembly.

