

**Tools Needed:**  
2.5mm Hex Key

***kuat***<sup>®</sup>

- ① Using the 2.5mm Hex Key, remove the two M4 counter-sunk screws attaching the Endcap to the center beam. Remove the old Front Endcap.

- ② Install the new Front Endcap by following step 1 in reverse.

