

**Tools Needed:**

6mm Hex Key, 6mm Hex Socket Bit

***kuat***<sup>®</sup>

- ① Open the tire arms of the rack. Using the 6mm Hex Key, remove the two old Tray Connector Bolts and Spacers. The bike tray can now be removed.

- ② Install the new Tray Connector Hardware by following step 1 in reverse. Torque the Tray Connector Bolts to 50 Nm.

