

**Tools Needed:**  
8mm Hex Key



**kuat**<sup>®</sup>

- ① Open the tire arms of the rack. Using the 8mm Hex Key, remove the two old Tray Connector Bolts and Spacers. The bike tray can now be removed.

- ② Install the new Tray Connector Hardware by following step 1 in reverse. Torque the Tray Connector Bolts to 35 Nm.

