

Tools Needed:
4mm Hex Key

kuat[®]

- ① Open the tire arm.
- ② Using the 4mm Hex Key, loosen but do not completely remove the Lower Tire Chock Bolt. Slide the Lower Tire Chock to the access slot located at the center of the tray and remove. Take note of the orientation of the Tire Chock Fastener.
- ③ Install the new Lower Tire Chock by following step 2 in reverse. Torque the M5 screw to 10 Nm.
- ④ Feed the Tire Strap through the slot in the Lower Tire Chock.

