

Tools Needed:
2.5mm Hex Key

kuat[®]

- ① Using the 2.5mm Hex Key, remove the two countersunk screws that connect the Rear Endcap to the center-beam. Remove the Rear Endcap.

- ② Install the new Rear Endcap by following step 1 in reverse.

