Tools Needed: 4mm Hex Key, 3mm Hex Key

- Küdt
- 1. Using the 4mm Hex Key, remove the M6 bolt and Latch Plate. 2. Using the 3mm Hex Key, remove the two M5 bolts and Door Latch.
- 3. Insert the new Door Latch. Using the 3mm Hex Key install the M5 bolts and washers. Torque to 6 Nm.
- 4. Turn the Door Latch to the open position and install the new Latch Plate and M6 bolt and washer.
- 5. Using the 4mm Hex Key, torque the M6 bolt to 10 Nm.



