

Tools Needed: 4mm Hex Key, 3mm Hex Key

1. Dislodge the Latch Rods by removing the Cotter Pins. Make sure to retain the Latch Rods, Cotter Pins, and Mounting Pins.
2. Using the 4mm Hex Key, remove the M6 bolt and Latch Plate.
3. Using the 3mm Hex Key, remove the two M5 bolts and Door Latch.
4. Insert the new Door Latch. Using the 3mm Hex Key install the M5 bolts and washers. Torque to 6 Nm.
5. Install the new Latch Plate and M6 bolt and washer using the 4mm Hex Key. Torque to 10 Nm.
6. Reinstall the Latch Rods by following Step 1 in reverse.

