

Tools Needed: 10mm Wrench

1. Dislodge the Latch Rod by removing the Cotter Pin.
2. Slide the Latch Rod out of the Bracket; retain Cotter Pin and Retaining Pin.
3. Using the 10mm Wrench, remove the two M6 Nuts and Washers.
4. Remove old Latch Rod Bracket and install the new Bracket. Note: the flange must face towards the center of the vehicle.
5. Using the 10mm Wrench torque the M6 Nuts to 10 Nm.
6. Reinstall the Latch Rod, Retaining Pin, and Cotter Pin by following steps 1-5 in reverse.

