

Tools Needed: 6 mm Hex Key

1. Using the 6 mm Hex Key, remove the four Crossbar Bolts.
2. Disconnect the Rear Auxiliary Light from the vehicle (See User Guide).
3. Team lift the Roof Panel off of the rack.
4. Follow steps 1-3 in reverse to reinstall the Roof Panel. Torque the M8 Crossbar bolts to 20 Nm.

