

Tools Needed: Flat Head Screwdriver

1. Open the Panel Door.
2. Release the Spring Clips on the door end of the Gas Spring by depressing the Red Lever.
3. The Gas Springs can now be dislodged from the Ball Stud Brackets. Note: the Flat Head Screwdriver can be used to gently pry the ball and socket joint apart if needed.
4. Open the Rear Door far enough that the door can come loose of the Hinges.
5. Remove the old Rear Door Panel and install the new Rear Door Panel by following step 4 in reverse.
6. Press the Gas Springs back onto the Ball Stud Brackets.

