

Tools Needed: 10 mm Security Hex Key, 5 mm Hex Wrench

1. Open the Rear Panel Door.
2. Using the 10 mm Security Hex Key, remove the J-Hooks from the Bed Clamps.
3. Team lift the rack 18" toward the rear of the vehicle.
4. Using the 5 mm Hex Wrench, remove the four M6 Bolts from the Front Panel.
5. The Front Panel can now be opened and removed.
6. Follow step 4 in reverse to reinstall the Front Panel. Torque the M6 Bolts to 12 Nm.
7. Follow steps 1-3 to reinstall the rack. Torque the Bed Clamps to 30-38 Nm.

