

Tools Needed: 10 mm Security Hex Key, Scraper, Scissors,
Isopropyl Alcohol

1. Open the Rear Panel Door.
2. Using the 10 mm Security Hex Key, remove the J-Hooks from the Bed Clamps.
3. Team lift the rack off of the vehicle and set it down in a way that you can access the bottom of the rack.
4. Using the Scraper and Isopropyl Alcohol, remove the old Weather Seal from the bottom of the IBEX.
5. Using the Scissors, trim the new Weather Seal if needed. Peel the adhesive backing from the new Weather Seal and stick it to the bottom of the IBEX.
6. Follow Steps 2 & 3 in reverse to reinstall the rack. Torque the Bed Clamps to 30-38 Nm.

