



Revision: 1.8 - 04/12/2012

Install Time: 60 Minutes

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

(2) 1/2" to 14mm Studs	(2) 12mm Nylock Nuts
(2) 12mm Washers	(2) 12mm Hex Nuts

INSTRUCTIONS:

- 1. Apply RED Loctite® on the 1/2" section of the supplied studs (this is the one with the course thread).**
- 2. Thread the stud into the bottom of the riser as tight as you can with your fingers. There is no need to use pliers or Vice Grips here!**
- 3. Repeat this procedure on the remaining riser.**
- 4. Slide the riser into the triple tree, and secure with a supplied washer and nylock nut.**

Note: We strongly recommend the application of Loctite®, or a similar material, on the threads of all bolts.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2013 Barons Custom Accessories