



PART#: DSB (1, 2, 3, 4, 6, 8, 10, 11, 13, 15)

(Installation Instructions)

1. Make sure ignition key is turned to the off position and engine is cool.
2. Place motorcycle on lift, rear stand, or side stand.
3. Locate the final destination of the new block off plates.
4. Carefully remove any fairings if needed.
5. Carefully remove fuel tank and air box.
6. Carefully remove any parts obstructing the OEM plates and then remove them.
7. Using blue Loctite, install the new block off plates using the OEM hardware,
8. and the OEM sealing "O rings" if present.
9. Locate OEM air hose leading to the airbox from the OEM plates removed.
10. Using supplied cap, remove hose and plug airbox.
11. Carefully replace airbox, fuel tank, fairings, and any other pieces removed during installation.

DRIVEN REQUIRES THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECHNICIAN

NOT INTENDED FOR STREET/HIGHWAY USE! FOR OFF ROAD/RACE USE ONLY!

DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN



PART#: DSB (1, 2, 3, 4, 6, 8, 10, 11, 13, 15)

(Installation Instructions)

1. Make sure ignition key is turned to the off position and engine is cool.
2. Place motorcycle on lift, rear stand, or side stand.
3. Locate the final destination of the new block off plates.
4. Carefully remove any fairings if needed.
5. Carefully remove fuel tank and air box.
6. Carefully remove any parts obstructing the OEM plates and then remove them.
7. Using blue Loctite, install the new block off plates using the OEM hardware,
8. and the OEM sealing "O rings" if present.
9. Locate OEM air hose leading to the airbox from the OEM plates removed.
10. Using supplied cap, remove hose and plug airbox.
11. Carefully replace airbox, fuel tank, fairings, and any other pieces removed during installation.

DRIVEN REQUIRES THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECHNICIAN

NOT INTENDED FOR STREET/HIGHWAY USE! FOR OFF ROAD/RACE USE ONLY!

DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN



PART#: DSB (1, 2, 3, 4, 6, 8, 10, 11, 13, 15)

(Installation Instructions)

1. Make sure ignition key is turned to the off position and engine is cool.
2. Place motorcycle on lift, rear stand, or side stand.
3. Locate the final destination of the new block off plates.
4. Carefully remove any fairings if needed.
5. Carefully remove fuel tank and air box.
6. Carefully remove any parts obstructing the OEM plates and then remove them.
7. Using blue Loctite, install the new block off plates using the OEM hardware,
8. and the OEM sealing "O rings" if present.
9. Locate OEM air hose leading to the airbox from the OEM plates removed.
10. Using supplied cap, remove hose and plug airbox.
11. Carefully replace airbox, fuel tank, fairings, and any other pieces removed during installation.

DRIVEN REQUIRES THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECHNICIAN

NOT INTENDED FOR STREET/HIGHWAY USE! FOR OFF ROAD/RACE USE ONLY!

DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN



PART#: DSB (1, 2, 3, 4, 6, 8, 10, 11, 13, 15)

(Installation Instructions)

1. Make sure ignition key is turned to the off position and engine is cool.
2. Place motorcycle on lift, rear stand, or side stand.
3. Locate the final destination of the new block off plates.
4. Carefully remove any fairings if needed.
5. Carefully remove fuel tank and air box.
6. Carefully remove any parts obstructing the OEM plates and then remove them.
7. Using blue Loctite, install the new block off plates using the OEM hardware,
8. and the OEM sealing "O rings" if present.
9. Locate OEM air hose leading to the airbox from the OEM plates removed.
10. Using supplied cap, remove hose and plug airbox.
11. Carefully replace airbox, fuel tank, fairings, and any other pieces removed during installation.

DRIVEN REQUIRES THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECHNICIAN

NOT INTENDED FOR STREET/HIGHWAY USE! FOR OFF ROAD/RACE USE ONLY!

DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN

