



Mounting Suggestions: Kawasaki Vulcan 900 Classic 2006-11 & Custom 2007-11 Tank Bib

Mounting of Mustang Tank Bib

1. Remove single dash 6 mm bolt with a 4 mm Allen wrench.
2. Lift rear of dash up about 1", then push forward off of mounting pins.
3. Place the cutout in Tank Bib over the speedometer, then under the front mounting pins. Pull bib back until the rear of cutout is over the dash mounting hole. Align front of dash with tank's mounting pins. Slide dash back until mounting hole lines up with hole on tank, then re-install the 6 mm Allen bolt. Tighten with a 4 mm Allen wrench.
4. Remove the two tank mounting bolts and washers with a 12 mm wrench. Re-install them through the holes in bottom of bib. Tighten with a 12 mm wrench.

Enjoy the custom look of your Mustang Tank Bib!



Plain



Studded



Step 1



Step 2



Step 3



Step 4



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern, or send an email to questions@mustangseats.com, or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Ref part #93197, 93198, 93306, 93307