

## **Mounting Suggestions** Yamaha V-Star 1100 Custom 1999-2011 & V-Star 1100 Classic 2000-2011 Tank Bib

Tools Required:

- Metric Allen Wrenches
- Metric Sockets

Hardware:

• Stock Rear Tank Mounting Bolt

## **Mounting of Mustang Fender Bib**

- 1. Remove seat.
- 2. Remove three Allen screws from speedometer bezel and lift bezel.
- 3. Lay tank bib around speedometer and reinstall bezel.
- 4. Use rear tank mounting bolt to secure rear of tank bib.
- 5. Reinstall seat.

## Enjoy the custom look of your new Mustang Tank Bib!

Plain Tank Bib



Studded Fender Bib



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern, or send an email to questions@mustangseats.com, or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Ref part # 93304, 93305, 93157, 93158