



Revision: 1.1 - 02/19/2010

INCLUDED IN THE KIT:

(4) - Socket Cap Shoulder Bolts	(2) - Mounting Brackets
(4) - 8mm Socket Cap Bolts	

INSTRUCTIONS:

NOTE: We recommend the use of blue Loctite on all fasteners.

1. Remove the stock floorboards by removing the pivot bolts from the bottom of the board where they attach to the frame bracket.
2. Install new Baron Longboard mounts with the supplied shoulder bolts and the stock nuts. The shorter of the bolts installs at the front of the floorboard mount.
3. Install the Longboard onto the mount with the supplied M8 cap head bolts. Position the boards so that you do not have interference with the heel shifter, engine guard, ect. (if equipped).
4. The heel strike pads on the bottom of the boards are replaceable if required after a period.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2013 Barons Custom Accessories