



# INSTALLATION

## DELUXE NECK COVER

8146

**FITS: ALL '95-'05 TOURING MODELS, DRESSER AND ROAD KING**

| PART #  | INCLUDED                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 408168C | 2 Clamp - Chrome                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 408168L | 1 Left Neck Cover — Chrome                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 408168R | 1 Right Neck Cover — Chrome                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 408168T | 2 Down Tube Cover — Chrome                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 908168  | 1 Hardware Kit Including: <ul style="list-style-type: none"><li>1 10-24 x 5/8" Socket Head Cap Screw</li><li>2 5/16" Flat Washer — Chrome</li><li>2 5/16"-18 x 1" Button Socket Cap Screw</li><li>4 8-32 x 1/2" Socket Head cap Screw</li><li>4 #8 Split Lock Washer — Chrome</li><li>1 #10 Split Lock Washer — Chrome</li><li>2 14" Black Cable Tie</li><li>2 Rubber Fork Stop</li><li>2 1" x 3-1/2" x 1/8" Foam Adhesive Pad</li><li>2 3/4" x 1-1/2" x .1" Foam Adhesive Pad</li></ul> |
| 200058  | 1 5/16"-18 X 5-1/2" Stud                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 200293  | 2 5/16"-18 Low Crown Acorn Nut                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 308146  | 1 Installation Instructions                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

*Please read and understand entire instructions before starting installation.*

### THANK YOU FOR CHOOSING KÜRYAKYN!

#### PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

#### NOTE

If you so choose, you may use blue thread lock to secure the fasteners used in this installation.

#### TOOLS SUGGESTED

1/2" Socket or Wrench, Standard Allen Wrench Set, Diagonal Cutter, and a Flat Tip Screwdriver

#### PROCEDURE FOR '98-'05

**STEP 1** Install the supplied foam adhesive pads on the inner surfaces of the covers as shown in **PIC.1**. Do not remove the inward facing paper from the pads adhered to the lower legs of the cover, as the cover should not be "stuck" to the frame. The pads are meant as an anti-vibration device only.

-cont.-

**PIC.1**



#### CUSTOMER SERVICE

877.370.3604 (toll free)

#### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

#### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).

- The product must be properly installed, maintained and operated under normal conditions.

- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.

- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.

- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.

- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

#### ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



**STEP 2** Remove the small machine screw and wiring harness clamp from the right side of the neck.

**STEP 3** Remove the stock 5/16"-18 fastener securing the front of the fuel tank on the right side using a 1/2" open-end wrench.

**STEP 4** Hold the right side cover in place on the neck and frame. Make sure the wiring harness and the throttle control cables run safely between the cover and the frame without being compromised. Loosely secure the right side cover with a supplied 5/16"-18 x 1" Button Socket Cap Screw and a 5/16" Flat Washer where the OEM fastener was removed in STEP 3.

**STEP 5** Remove the stock 5/16"-18 fastener securing the front of the fuel tank on the left side using a 1/2" open-end wrench.

**STEP 6** Hold the left cover in place on the neck and frame. Loosely secure the cover using a supplied 5/16"-18 x 5/8" socket head cap screw and a 5/16" Flat Washer where the OEM fastener was removed in STEP 5.

**STEP 7** On the right and left frame down tubes below the lower clamp portion of the neck cover, snap the down tube covers in place. Be sure the clamp portion of the neck cover will slightly overlap the down tube cover.

**STEP 8** On the top of the right side cover you will find a fastener hole. Loosely secure the cover halves to each other through this hole using the supplied 10-24 x 5/8" Socket Head Cap Screw with the #10 Split Lock Washer.

**STEP 9** On the lower legs of both the left and right side, loosely install the clamps using the supplied 8-32 x 1/2" Socket Head cap Screws with the #8 Split Lock Washers. Make sure the clamps are in the correct orientation so they match the tapered edge of the lower legs.

**STEP 10** Slip a rubber fork stop bumper over the stock fork stop "donut" (located on the fork tube) on the right side of the bike and secure it using one of the supplied nylon zip ties. Adding this extra cushion on the left side is usually not necessary and may interfere with fork stop operation.

**STEP 11** Starting with the 5/16"-18 x 1" Button Socket Cap Screw, tighten all seven fasteners snugly.

## PROCEDURE FOR '95-'97 MODELS

**STEP 1** Install the supplied foam adhesive pads on the inner surfaces of the covers as shown in [PIC.1](#). Do not remove the inward facing paper from the pads adhered to the lower legs of the cover, as the cover should not be "stuck" to the frame. The pads are meant as an anti-vibration device only.

**STEP 2** Remove the small machine screw and wiring harness clamp from the right side of the neck.

**STEP 3** Remove the stock 5/16"-18 x 5" bolt and nut securing the front of the fuel tank.

**STEP 4** Hold the right side cover in place on the neck and frame. Make sure the wiring harness and the throttle control cables run safely between the cover and the frame without being compromised. Insert the supplied 5/16"-18 x 5-1/2" Stud through the cover, tank tab and the mounting hole. Hold the Left side cover in place being sure that an equal length of the stud is protruding through the covers on both sides of the bike. Loosely secure both side covers using the supplied 5/16" Flat Washers and 5/16"-18 Low Crown Acorn Nuts.

**STEP 5** On the right and left frame down tubes below the lower clamp portion of the neck cover, snap the down tube covers in place. Be sure the clamp portion of the neck cover will slightly overlap the down tube cover.

**PIC.1**



**STEP 6** On the top of the right side cover you will find a fastener hole. Loosely secure the cover halves to each other through this hole using the supplied 10-24 x 5/8" Socket Head Cap Screw with the #10 Split Lock Washer.

**STEP 7** On the lower legs of both the left and right side, loosely install the clamps using the supplied 8-32 x 1/2" Socket Head cap Screws with the #8 Split Lock Washers. Make sure the clamps are in the correct orientation so they match the tapered edge of the lower legs.

**STEP 8** Turn the handlebars as far as they will go in each direction to check for contact between the fork and the neck covers. If contact is detected on either side, slip a rubber fork stop bumper over the stock fork stop "donut" (located on the fork tube) on the affected side and secure it with one of the included nylon zip ties. Adding this extra cushion on the left side is usually not necessary and may interfere with fork lock operation.

**STEP 9** Starting with 5/16"-18 Low Crown Acorn Nut on each end of the stud, tighten all seven fasteners snugly.

*Ride On!*

**Kuryakyn**