



INSTALLATION

PLUG AND PLAY SISSY BAR MOUNT 8998

PARTS INCLUDED

- 1 Plug and Play Sissy Bar Mount
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

TOOLS SUGGESTED

Set of Hex Wrenches, Combination Wrenches, Socket Set and Ratchet, Drill Bits, Drill, Masking Tape.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

ATTENTION! This procedure may require making permanent modifications to the fender; this may void your warranty. Consult your dealer for more information.

NOTE: This product is recommended for use on steel fenders only.

NOTE: Accepts aftermarket or OEM H-D sissy bar uprights that are NO MORE THAN 10" TALL, 6-11/16" wide- this sissy bar is commonly used on FXR's, '91-'01 Dynas, and '03-earlier Sportsters

STEP 2 Remove the seat from the motorcycle and clean the fender.

STEP 3 Place the mount on the fender and determine a mounting location; you may choose to slightly bend the backbone to conform to the contour of the fender for a better fit.

8998-21HD-0911

-cont.-



CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.

kuryakyn.com



STEP 4 Once a location has been determined, fit the seat to make sure the location of the bracket will work with the seat.

NOTE: Generally the rear mounting hole in the mounting plate will be placed so that it will be secured with the rear seat mounting bolt, though it may be positioned in any location by drilling two holes.

STEP 5 Once mounting location has been determined, place masking tape on the fender in the location where the hole(s) will be drilled and mark the hole location.

STEP 6 Carefully drill a hole(s) in the marked location(s), using the appropriate sized drill bit for the hardware that you chose to secure the mount; be careful not to drill into the tire.

CAUTION! **MEASURE TWICE – DRILL ONCE.** Double check all reference marks made on the rear fender **BEFORE** drilling. Kuryakyn will not be responsible for incidental or consequential damages resulting from this installation.

CAUTION! Ensure that the area below the fender is clear before drilling. Be careful not to drill into the tire or any concealed wiring!

CAUTION! To minimize the possibility of damage to the paint we recommend the use of masking tape and a sharp drill bit.

STEP 7 Carefully remove the tape from the fender.

STEP 8 Thoroughly clean the fender to remove any metal shavings and/or dust, dirt or grime to prevent damage to the paint.

STEP 9 Place the mount on the on the fender and secure using your hardware, ensuring that any hardware will not be too long and interfere with the tire at any point during operation of the motorcycle.

NOTE: If using existing holes make sure to use the proper thread pattern, washer and bolt size specific to your fender.

CAUTION! Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

STEP 10 Install a sissy bar that is no more than ten (10) inches (not included) and secure to the bracket.

WARNING! DO NOT EXCEED 10" HEIGHT RESTRICTION-USE OF TALLER SISSY BARS MAY RESULT IN FENDER DAMAGE, SERIOUS INJURY OR DEATH.

STEP 11 Tighten all hardware securely.

WARNING! SISSY BARS ARE NOT A SAFETY RESTRAINING DEVICE. FAILURE TO HOLD ONTO THE MOTORCYCLE MAY RESULT IN INJURY OR DEATH.

WARNING! IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.