



.....Mounting Suggestions
Harley-Davidson® Dyna Glide &
Dyna Wide Glide 1996- 2005
.....Two-Piece Seat

Tools Required:

- Phillips Screwdriver
- Allen Wrench Set

Hardware:

- Stock Rear Fender Screw
- Solo Seat
- Nut Insert Kit w/Instructions (Included)
- Passenger Seat
- Chrome Mounting Bracket (Included)
 - Chrome 1/4"-20 Allen Bolt (Included)



Baseplate Features:

Solo and passenger seat feature formed steel baseplate with polyurethane bumpers strategically located to prevent them from touching the frame and to minimize vibration.

NOTE: Mustang Passenger Seats work ONLY with Mustang Solo Seats.

Removal of Stock Seat

1. Remove rear fender screw and set aside. The stock rear fender screw will be used to attach your new Mustang Seat.
2. If applicable, remove seat strap.
3. Slide seat back and lift up to remove.

Mounting of Mustang Solo

1. Install nut insert kit if needed. Note: Spool washer shown is used for rear seat mounting only. (Fig. 1)
2. Engage nose tab of seat into frame.
3. Align chrome rear tab with threaded mount in fender.
4. Secure the rear of the solo seat to the fender with stock fender screw to complete the installation process.

Fig. 1



Solo with matching fender bib

