



MOUNTING SUGGESTIONS:

Harley-Davidson® FL “Air Ride” style 1997-2017 Passenger Seat

Hardware:	Stock ¼"-20 x ½" screw 78028 (1997-1998) or 78032 (1999-2016) (not included) or stock hardware Black nylon washer
Tools needed:	7/16" (1997-1998) or 5/8" (1999-2016) open-end Wrench Phillips screwdriver

Installation or Mustang solo seat:

This Mustang passenger seat will install behind either the stock solo or a Mustang solo.



1. 1997-1998 – insert the stock slotted bolts or Mustang part 78028 securely into the nuts in the front of the fender.
2. 1999-2016 – install the slotted nuts or Mustang part 78032 securely onto the stud plate on the front of the fender.
3. Slide the front brackets of the passenger seat into the slotted bolts or nuts.
4. Place the black nylon washer between fender and rear bracket, and secure the seat to the fender with the stock screw.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part number: 79428, 79436

**You are cordially invited to
— Tour the Mustang Factory —**

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.