



Revision: -

INCLUDED IN THE KIT:

(1) Chrome or Black Big Johnson Handlebar for Throttle-By-Wire Equipped Models	
--	--

TOOLS REQUIRED:

5/32, 3/16, 1/4 & 5/16" Allen Wrenches	T25 & T40 Torx Sockets
10mm, 7/16 & 7/8" Open-End Wrenches	Phillips & Flat Screwdrivers
Wire Cutters	Factory Service Manual
Pliers (Std. & Needle-nose)	Soldering Iron & Shrink Wrap Tubing

INSTRUCTIONS:

--

<p>Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product. © 2014 Barons Custom Accessories</p>
--