



MOUNTING SUGGESTIONS:

Harley-Davidson® FL Touring 2008-2015 Solo Seat

Hardware (Included):	Slotted mounting nuts x 2 Black nylon shoulder washer x 2 Chrome washer x 2 Mini Fender Bib
Tools needed:	Phillips screwdriver 5/8" deep socket or open-end wrench 7/16" open-end wrench

Removal of Stock Seat:

Two-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.

2. Slide the rear seat back and up.

3. Remove the two nuts holding the solo in place.

4. Carefully lift the back of the driver's seat up and back to disengage the front bracket and remove the seat.



One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.

2. Remove hand strap that is secured to the motorcycle on each side of the seat where the front saddlebag mount is located.

3. Slide the seat up and back to disengage the front bracket and remove the seat.

Installation of Mustang Seat:

1. Remove any seat supports from the frame rails and be sure wiring is routed along the inside of the frame rails.
2. Engage the nose bracket into the frame. Push it as far forward as possible so that the mounting studs in the fender are in the middle to back edge of the slotted rear tabs.
3. A firm downward punch or chop to the nose of the seat will push the seat closer to the chrome dash. If there is a gap at the dash, the dash can be adjusted by loosening the $\frac{1}{2}$ " hex nut and Phillips screw on the dash, sliding the dash back and retightening.
4. The seat is spring-loaded, so the rear mounting bracket will be approximately 1" to 1-1/2" above the fender mounts. Place the supplied mini-bib over the stud plate on the fender if desired.



5. Place the nylon shoulder washers on the fender studs and then put the rear mounting tabs over the studs.
6. Place the chrome washers over the studs and secure the seat with the slotted solo mounting nuts. Tighten both finger tight, then tighten both securely.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 76026, 76027, 76028, 76029, 76067, 76068, 76069, 76692, 76694, 76713, 76720, 76722, 79446, 79447, 79448, 79600, 79601, 79602, 79719, 79725, 79810, 79811

You are cordially invited to
— Tour the Mustang Factory —

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.