



Product information sheet

Nissan Bluetooth Bypass AX-NIS32BT

The following Nissan Vehicles come equipped with a Bluetooth module that must be bypassed when installing an ASWC-1 (sold separately) in order to retain the Bluetooth buttons on the steering wheel.

APPLICATIONS

350Z	2007-2009	Frontier	2008-2011	NV200	2013-2017	Versa	2007-2016
370Z (w/o nav)	2010-2014	Frontier (w amp)	2013-2015	NV2500	2012-2013	Versa Note	2014-2015
370Z	2015-2016	Juke	2011-2014	Rogue	2008-2013	Xterra	2007-2015
Altima	2007-2012	Leaf	2012-2015	Sentra	2007-2015		
Cube	2009-2014	Maxima	2006-2014	Titan	2008-2014		

BLUETOOTH MODULE LOCATIONS

350Z 2007-2009	Top of Trunk	Maxima 2006-2014	Under rear deck in trunk
370Z 2010-2014 (w/o nav)	Top of Trunk	NV200 2013-2017	Behind glovebox
370Z 2015-2016	Top of Trunk	NV2500 2012-2013	Behind glovebox
Altima 2007-2012	Rear deck	Rogue 2008-2013	Trunk left side
Cube 2009-2014	Under front passenger seat		luggage compartment
Frontier 2008-2011	Under front seat	Sentra 2007-2015	Behind glovebox
Frontier 2013-2015 (w/ amp)	Under front seat	Titan 2008-2014	Under front passenger seat
Juke 2011-2014	Behind glovebox	Versa 2007-2016	Right side of trunk
Leaf 2012-2015	Trunk right hand side of luggage compartment	Versa Note 2014-2015	Right side of trunk
		Xterra 2007-2015	Under front passenger seat

INSTALLING

1. Install and program the ASWC-1, then test all buttons for proper function.

Note: Bluetooth buttons will not work until Step 2 is done.

For ASWC-1 vehicle instructions, please refer to the AXXESS website: <https://axxessinterfaces.com/>

2. Locate the Bluetooth module, disconnect the 32-pin harness, and then connect the AX-NIS32BT to the harness removed.
3. Test that the Bluetooth buttons now function.

Note: Ensure that the phone is paired to the aftermarket radio.