



If the interface fails to function, press and release the reset button, then repeat the programming process from step 3 to try again.

1. Open the driver's door, and keep open during the programming process. Cycle the ignition on.
2. Connect the WM-CH13-SWC harness to the WM-CH13-SWC interface, and then to the wiring harness in the vehicle.
Note: Use only the vehicle harness that fits and disregard the other.
3. For models with steering wheel controls: Tap the Volume Up button on the back of steering wheel until the LED stops flashing.
4. The LED will flash Green & Red while the interface learns the radio. The LED will go out, flash, then turn solid Green.
5. Cycle the ignition off/on, then test all functions for proper operation