



# WALLPAPER

## HANGING INSTRUCTIONS:

### WHAT YOU WILL NEED:

- Soft Dry Cloth
- Lightly Dampened Cloth
- Sharp Knife
- Paste Brush/Roller
- 'Paste the Wall' Wallpaper Adhesive
- Step Ladder
- Plumb Line or Spirit Level
- Pencil
- Ruler

### TO PREPARE YOUR WALL:

Ensure the wall surface is clean, dry and free of any mildew and grease and is as smooth as possible to achieve the best possible results.

Ensure all previous wallpaper, lining paper and adhesive have been removed from the wall before hanging.



### GETTING STARTED:

1. When your wall is fully prepared, use a plumb line or spirit level to ensure you have a straight line to begin hanging your wallpaper. The position of the first strip determines the overall look of the completed wall, so take time to hang it accurately.
  2. When ready to start hanging your paper, be prepared to continue until all the wallpaper has been hung, avoiding long periods between hanging each piece. Make sure you work from left to right.
  3. Measure the length of your wall, adding a slight excess, so that you can trim accordingly with your sharp knife once on the wall.
  4. Be sure to find where the wallpaper joins before you apply to the wall. See the wallpaper packaging for details.
  5. Apply 'Paste the wall' adhesive to the wall, covering enough area for the strip.
  6. Apply the first strip to the wall, lining up to your plumb line/straight edge. Use a soft cloth to gently work any large air pockets downwards and outwards. Take care not to overwork each strip as this could result in stretching, making it harder to line up following strips.
  7. Carefully remove any excess paste from the front of the wallpaper using a lightly dampened cloth. Too much rubbing or cleaning may remove ink from the paper.
  8. Repeat steps 3 to 7 for the remaining strips of your wallpaper, lining up the design and tightly butting up each join so no gaps can be seen.
  9. Trim any excess edges carefully after applying the paper.
  10. When all the strips of the wallpaper have been hung, remove any excess wallpaper paste from the wall with a damp cloth.
- 
- 