



Environmental Health & Sanitation Chemicals

Technical Data



SHOCK & AWE



HIGH POWER URINAL RENOVATOR

DESCRIPTION

This high powered, high acid cleaner powers away tough scale, rust, and mineral deposits like never before. It completely dissolves uratic salts, iron, and calcium that cause unsightly stains in toilets and urinals – yet is completely safe for these surfaces and is odor free.

Shock & Awe rapidly penetrates, breaks up and liquefies build ups in drain lines that cause embarrassing urinal back ups. Scale, lime, and urinal drain line odors are a thing of the past when preventatively treated on a regular basis.

Shock & Awe excels in restoring fiberglass boat hulls to like new condition too. Whether it be on the Great Lakes, the ocean, or inland lakes and rivers – **Shock & Awe** effortlessly powers away tough stains from algae, inorganic scum lines, organic debris and mineral deposits leaving a sparkling clean boat hull behind. Truly amazing results have to be seen to be believed!

PRECAUTIONS

CAUTION: Keep out of reach of children. For industrial and institutional use only by trained personnel. Material Safety Data Sheet available.

USES / BENEFITS

- Dissolves uratic salts
- Restores slow running urinals to original flow
- Eliminates urine odor
- Demineralizes boat hulls
- Removes rust

SPECIFICATIONS

Color Milky White
 Fragrance Pungent
 Form Thin Liquid
 pH < 1
 Shelf Life 2 years minimum
 Specific Gravity 1.112

DIRECTIONS FOR USE

URINAL CLEANING: Flush urinal to remove residual soils. Remove screens and strainers. Apply Shock & Awe liberally with the squeeze top, never use a trigger sprayer, starting from the inside bottom of the urinal up to the top of the urinal. Allow product to dwell several minutes to power away tough stains and odors. Agitate with a bowl swab, then flush to rinse surface. Before replacing screens and strainers, pour 6-8 ounces into drain to completely dissolve drain lines deposits. Allow to stand several minutes, flush, and replace screens. Don't forget to replace the Urine Catchers, and/or, Sun Tabs for maximum urinal care. **TOILET BOWL CLEANING:** Flush to rinse out bowl. Using bowl swab, force water out of trap to reduce level remaining in bowl. Using directional spout, apply Shock & Awe liberally under rim allowing product to flow down the sides of the bowl. Swab entire bowl, and allow to stand several minutes. Flush to rinse. **SLOW RUNNING URINAL DRAINS:** Pour one quart of Shock & Awe into urinal drain. Allow to work for 10 minutes as product completely dissolves uratic salt accumulations and odors. Flush urinal twice. Repeat on a regular maintenance basis. **BOAT HULLS:** Wear rubber gloves, goggles/face shield, and protective clothing when using this product. Test surfaces for compatibility on a small and inconspicuous area before use. Avoid contact with metal surfaces. Use a polyethylene (plastic) cover to protect boat trailers. Safe on fiberglass and painted wood surfaces when used as directed. If there are breaks or blisters in the gel coat avoid application in those areas. Apply product to dry hull using squeeze cap, or saturate mop and then apply to hull. Start at the bottom of hull and work towards the top. Focus on a 3-4 foot section at a time, so area remains wet while cleaning. Spread product evenly over surface, allow to dwell several minutes, agitate, and rinse area completely. Continue repeating process until entire hull is cleaned.

EXCELLENCE
 SINCE
 1964

"Exclusive Distributors Of  Chemicals"

800.242.7694 • www.northwoodstm.com

