

### Universal Custom Pre-Inked Stamp



- 1 Turn stamp upside down.
- 2 Place stamp in re-inking fluid box as shown or between two thick books.
- 3 Squeeze a few drops of re-inking fluid over the raised characters.
- 4 Let the stamp sit upside down overnight to allow ink to absorb into the stamp.
- 5 The next morning, blot excess ink by making a few impressions on a sheet of scrap paper. Repeat Step 3 if necessary.



### Universal Stock Pre-Inked Stamp



- 1 Remove stamp handle.
- 2 Place two drops of ink in each black vertical column, replace stamp handle.
- 3 Let the stamp sit overnight to allow ink to absorb into the stamp.
- 4 The next morning, blot excess ink by making a few impressions on a sheet of scrap paper. Repeat Step 2 if necessary.



### Universal Stock Pre-Inked Round Stamp



- 1 Turn stamp upside down and remove dust cover.
- 2 Place 1-2 drops of ink directly on the stamp die.
- 3 Let stamp sit overnight to allow ink to absorb into the stamp.
- 4 The next morning, blot excess ink by making a few impressions on a sheet of scrap paper. Repeat Stamp 2 if necessary.

