





## NOTES:

- 1. USE FILTER MAT SEDIMENT BARRIER WHEN CURB INLET IS LOCATED IN GENTLY SLOPING STREET, WITH MINIMAL NEED, WHERE WATER CAN FILTER AND ALLOW SEDIMENT TO SEPARATE FROM RUNOFF.
- 2. BARRIER SHALL ALLOW FOR OVERFLOW FROM SEVERE STORM EVENT.
- 3. INSPECT BARRIERS AND REMOVE SEDIMENT AFTER EACH STORM EVENT. SEDIMENT MUST BE REMOVED FROM THE TRAVELED WAY IMMEDIATELY.



## CITY OF WARR ACRES

CONSTRUCTION SITE RUNOFF STANDARD DETAILS

## CURB INLET FILTER MAT SEDIMENT BARRIER

REVISION DATE: MARCH 2009

STORM SEWER: EC-12

PAGE NO. 12