



Baffle for the PublicLab Spectrometer 3.0

If you have black card stock, print this page out. The printed lines will be easily seen if you use a laser printer.

If you do not have black card stock, print out the following page. Blacken the opposite side with a magic marker.

Cut out the design, and fold it into a box shape. Affix the tabs with glue or tape. Place a short strip of the hook type Velcro on the bottom surface. Position it on the bench with the slit in the middle. (See diagram below.)



