



# TIRE PATCH

## **TIRE PATCH – FOR USE WITH INNER TUBE TIRES ONLY**

**DIRECTIONS:** Prepare tire by buffing until black rubber is exposed and all foreign material disappears. Apply liberal amount of cement and let dry until tacky. Remove backing from patch, **DO NOT TOUCH EXPOSED SURFACE!** Align arrows on patch to point at bead of tire. Apply patch to cemented area. Use stitch tool to force out trapped air.

## **PARCHE PARA LLANTAS – PARA USARSE SOLAMENTE CON LLANTAS DE CÁMARA INTERNA**

**MODO DE APLICACIÓN:** Prepare la llanta raspando hasta que el caucho negro quede expuesto y desaparezca todo el material extraño. Aplique libremente cemento y deje secar hasta que esté pegajoso. Desprenda el revestimiento del parche **SIN TOCAR LA SUPERFICIE EXPUESTA**. Alinee las flechas del parche para que apunten hacia el reborde de la llanta. Aplique el parche en el área con el cemento. Use un instrumento para costura para expulsar el aire atrapado.

©Accessories Marketing, Inc. 800 Farroll Road, Grover Beach, CA 93433 USA | P.O. Box 197, Oaklands Park, SA 5046 Australia [www.slime.com](http://www.slime.com)

PART# 1028-A 09.09



7 1628100049 2

Made in China