



20 PATCHES

Proper Use:

- Lightly buff* area around puncture. Remove loose particles. Make sure area within 1/2" (1.25 cm) of puncture has roughened appearance.
- Squeeze rubber cement* onto roughened surface and spread evenly. Work into material and wait until tacky.
- Remove the blue plastic backing from patch without touching exposed surface.
- Apply repair material directly over puncture and press firmly. Remove clear plastic backing. Using a stitching tool, ensure the edges of the patch are firmly attached.

*Buffer and rubber cement not included

Uso Apropiado:

- Raspe* ligeramente el área alrededor de la punción. Retire las partículas sueltas. Asegúrese de que el área dentro de 1/2" (1.25 cm) de la punción tenga apariencia áspera.
- Presione el cemento de caucho* sobre la superficie áspera y esparza de manera uniforme. Frote el material hasta que quede pegajoso.
- Desprenda el recubrimiento plástico transparente del parche sin tocar la superficie que queda expuesta.
- Aplique el material de reparación directamente sobre la punción y presione con firmeza. Retire el recubrimiento fino metálico. Use un instrumento de costura para asegurar que los bordes del parche queden adheridos firmemente.

*No incluye solución amortiguadora ni cemento de caucho

PART# 1035-A

08.13.10



7 1628100046 1

Made in China

©Accessories Marketing, Inc.

800 Farroll Road, Grover Beach, CA 93433 USA
P.O. Box 197, Oaklands Park, SA 5046 Australia

www.slime.com