



## ***6 PRE-GLUED PATCHES, SCUFFER & TIRE LEVERS***

### **TO APPLY PRE-GLUED PATCHES:**

- Roughen puncture area with enclosed metal scuffer and wipe clean
- Peel off the patch backing while not touching or allowing the adhesive to become contaminated
- Apply patch over the puncture and press firmly
- Insert inner tube into the tire casing and reinflate



### **TO USE TIRE LEVERS:**

- Deflate tire completely
- Insert end of tire lever between tire bead and rim, prying back to raise tire bead above lip of rim
- To keep in place, attach hooked end of lever to a wheel spoke
- Insert other lever between tire and rim about 3 to 4 inches from the first lever
- Pull back on lever and slide lever around rim to unseat the tire

