



56 PATCHES

Proper Use:

- Lightly buff area around puncture. Remove loose particles. Make sure area within 1/2" (1.25 cm) of puncture has roughened appearance.
- Squeeze rubber cement onto roughened surface and spread evenly. Work into material and wait until tacky.
- Remove clear plastic backing if present. Do not touch exposed surface.
- Apply repair material directly over puncture and press firmly. Remove foil backing. Using a stitching tool, ensure the edges of the patch are firmly attached.

Uso Apropiado:

- Raspe ligeramente el área alrededor de la punción. Retire las partículas sueltas. Asegúrese de que el área dentro de 1/2" (1.25 cm) de la punción tenga apariencia áspera.
- Presione el cemento de caucho sobre la superficie áspera y esparza de manera uniforme. Frote el material hasta que quede pegajoso.
- Desprenda el recubrimiento plástico transparente del parche sin tocar la superficie que queda expuesta.
- Aplique el material de reparación directamente sobre la punción y presione con firmeza. Retire el recubrimiento fino metálico. Use un instrumento de costura para asegurar que los bordes del parche queden adheridos firmemente.