

U7147

U4362

U7172

U1551

U7177

U7148

U7145

U1960

U7172

U7171

U7172

U7557

U613

U7261

See list above

U613

U7261

U7432

U1960

U7209

U7231

U7589

U7273	Vintage Springs Med 4.0lb/in (pr)
U8329	Vintage Springs Med Grey 2.7lb/in (pr)
U8330	Vintage Springs Med Blue 3.0lb/in (pr)
U8331	Vintage Springs Med Black 3.3lb/in (pr)
U8332	Vintage Springs Med Set (6pr)
U8362	Vintage Springs Med Green 3.6lb/in (pr)
U8363	Vintage Springs Med Orange 4.4lb/in (pr)

U2722	Vintage Springs Short 6.0lb/in (pr)
U8328	Vintage Springs Short Set (7pr)
U8364	Vintage Springs Short Green 5.2lb/in (pr)
U8365	Vintage Springs Short Purple 6.9lb/in (pr)
U8366	Vintage Springs Short Orange 8.0lb/in (pr)
U8367	Vintage Springs Short Grey 3.5lb/in (pr)
U8368	Vintage Springs Short Blue 4.0lb/in (pr)
U8369	Vintage Springs Short Black 4.5lb/in (pr)

Exploded view diagram of a shock absorber assembly. The components are labeled with part numbers in boxes:

- U1547
- U7147
- U4362
- U7172
- U7176
- U1551
- U7149
- U1960
- U7172
- U7171
- U7709
- U1960
- U7172
- U835
- U7172
- U7557
- U1548
- U7172
- U7332
- U613
- U726
- See list above
- U1960
- U1548
- U7172
- U613
- U7261
- U7432
- U7431
- U7367
- U7367

U5147 Bodyshell + Decals + Window Mask - Cougar
U5148 Wing and Endplates - Cougar
U8294 Decals - Cougar (pk3)



Schumacher