



TACTICAL ADJUSTABLE BATTLESIGHT (TAB) INSTALLATION INSTRUCTIONS

- REMOVE SLIDE FROM PISTOL AND SECURE IN PADDED VISE TO PROTECT ITS FINISH.
- REMOVE OLD SIGHT.
- CLEAN AND DEGREASE DOVETAIL CUT ON THE SLIDE FOR NEW SIGHT.
- LOOSEN SIGHT T-10 TORX SET-SCREWS AND ENSURE THEY ARE ABOVE THE SIGHT'S BOTTOM DOVETAIL SURFACE.
- TEST YOUR FIT BY PUSHING REAR SIGHT IN DOVETAIL FROM RIGHT TO LEFT (LOOKING AT TOP OF SLIDE).
- IF SIGHT DOESN'T START IN DOVETAIL REMOVE MATERIAL FROM THE FRONT AND BACK OF THE SIGHT DOVETAIL USING A SAFE EDGE DOVETAIL FILE UNTIL THE SIGHT BEGINS TO START SLIDING INTO THE SIGHT CUT. IF SIGHT IS EXCESSIVELY LOOSE IN THE DOVETAIL, YOU MAY NEED TO PEEN YOUR SIGHT FOR A BETTER FIT OR ADD MATERIAL TO YOUR DOVETAIL.
- TAP SIGHT INTO PLACE WITH A NON-MARRING (BRASS, ALUMINUM) PUNCH ON THE DOVETAIL AREA. CENTER IN SLIDE OR ADJUST WINDAGE TO YOUR PREVIOUS SIGHTS LOCATION AND LOCK DOWN THE T-10 TORX HEAD SET SCREWS WITH FIRM HAND PRESSURE ONLY.
- FOR A SEMI-PERMANENT INSTALLATION USE BLUE LOCTITE IN THE SIGHT DOVETAIL OR ON THE SIGHT SCREW THREADS.

DISCLAIMER: WILSON COMBAT 1911 SMALL PARTS MAY REQUIRE MINOR FITTING AND SHOULD ONLY BE INSTALLED BY A QUALIFIED GUNSMITH. ALTHOUGH THESE PARTS ARE INTENDED TO BE DROP-IN, DUE TO THE RANGE OF TOLERANCES BETWEEN VARIOUS MANUFACTURERS' HANDGUNS, SOME FITTING MAY OCCASIONALLY BE NECESSARY. WE HIGHLY RECOMMEND ALL FITTING/INSTALLATION OF SMALL PARTS IS DONE BY A PROFESSIONAL GUNSMITH.