



## WCP320 INSTALLATION INSTRUCTIONS

- UNLOAD AND CLEAR YOUR PISTOL
- REMOVE THE SLIDE ASSEMBLY AND SET IT ASIDE.
- REMOVE THE TAKEDOWN LEVER OUT OF THE FACTORY GRIP FROM LEFT TO RIGHT AND SET ASIDE. YOU MAY NEED TO TWIST/TAP THE TAKEDOWN LEVER OUT WITH A NON-MARRING TOOL AS IT IS RETAINED BY A SPRING IN THE CHASSIS.
- LIFT THE CHASSIS STRAIGHT UP FROM THE REAR AT A FORWARD ANGLE OUT OF THE STOCK FRAME.
- INSTALL SUPPLIED MAGAZINE CATCH, SPRING, AND LOCK INTO THE WCP320 GRIP MODULE.
- REVERSE THE PROCESS TO INSTALL THE CHASSIS INTO THE GRIP FRAME AND RE-INSTALL THE TAKEDOWN LEVER.
- YOU MAY NEED TO TAP THE TAKEDOWN LEVER IN PLACE WITH A NON-MARRING TOOL.
- REINSTALL THE SLIDE ASSEMBLY AND MOVE THE TAKEDOW LEVER INTO THE LOCKED POSITION.
- ENSURE THAT YOUR PISTOL FUNCTIONS PROPERLY AND YOUR MAGAZINE DROPS CLEANLY AFTER INSTALLATION OF THE NEW GRIP FRAME PRIOR TO USE.