



## **BULLET-PROOF AMBI SAFETY SELECTOR INSTALLATION INSTRUCTIONS**

- REMOVE PISTOL GRIP, SAFETY SPRING, SAFETY DETENT, AND OLD SAFETY FROM LOWER RECEIVER.
- INSERT THE RIGHT SIDE OF NEW SAFETY INTO THE LOWER RECEIVER, RETAINING TAB FIRST INTO THE RECEIVER HOLE, AND THEN ROTATE SO THE TAB RESTS AGAINST THE INSIDE OF THE RECEIVER POCKET.
- USE A DAB OF HEAVY GREASE TO RETAIN THE SAFETY SPRING IN THE CENTER HOLE OF THE LEFT SIDE OF NEW SAFETY DURING ASSEMBLY.
- INSERT THE LEFT SIDE OF NEW SAFETY INTO THE LOWER RECEIVER WHILE LINING UP END SLOT WITH THE CORRESPONDING BOSS ON THE RIGHT-SIDE SAFETY.
- USE ONE HAND TO KEEP BOTH SAFETIES COMPRESSED TOGETHER AGAINST THE CENTER SPRING PRESSURE WHILE REINSTALLING SAFETY DETENT, SAFETY SPRING, AND PISTOL GRIP WITH THE OTHER HAND.
- THE SAFETY DETENT WILL KEEP THE LEFT SIDE OF THE SAFETY IN PLACE, WHILE THE RETAINING TAB WILL KEEP THE RIGHT SIDE LEVER FROM BECOMING DISLODGED DURING USE.
- RE-ASSEMBLE AN UNLOADED AR AND CHECK SAFETY FUNCTION.

### **WARNING :**

WILSON COMBAT RIFLE PARTS ARE INTENDED TO PROVIDE AN EASY DROP-IN FIT, BUT DUE TO THE VARIANCE IN MANUFACTURER TOLERANCES IT IS POSSIBLE THAT SOME MINOR FITTING MAY BE NECESSARY FOR PROPER INSTALLATION. IF YOU LACK EXPERIENCE IN YOUR ABILITY TO PROPERLY INSTALL THESE PARTS WE STRONGLY RECOMMEND CONSULTING WITH A PROFESSIONAL GUNSMITH PRIOR TO PROCEEDING. FAILURE TO DO SO COULD POTENTIALLY RESULT IN SERIOUS INJURY OR DEATH. USE AT YOUR OWN RISK.