

## COLT PYTHON/ANACONDA BATTLESIGHT INSTALL INSTRUCTIONS

- MAKE SURE YOUR REVOLVER IS UNLOADED.
- PLACE YOUR REVOLVER ON A NON MARRING BENCH BLOCK OR HOLD IN A PADDED VISE BY THE BARREL
- TIGHTEN YOUR REAR SIGHT ELEVATION SCREW ALL THE WAY DOWN TO LOCK SIGHT IN PLACE
- USING A 1/16" PUNCH AND SMALL HAMMER, REMOVE YOUR OLD REAR SIGHT RETAINING ROLL PIN WHILE ENSURING THAT YOU DO NOT MAR THE FRAME.
- REMOVE THE ELEVATION SCREW AND REAR SIGHT ASSEMBLY AND CLEAN THE SIGHT RECESS WITHOUT LOSING ANY PARTS-(THERE IS A SMALL DETENT AND SPRING UNDER THE SCREW.)
- INSTALL NEW REAR SIGHT WITH NEW ELEVATION SPRING UNDER THE ELEVATION SCREW, CHECKING FIT IN YOUR FRAME. INSTALL ELEVATION SCREW ALL THE WAY DOWN.
- TAP IN NEW SUPPLIED ROLL PIN WITH NON MARRING HAMMER OR PUNCH. SEAT WITH 1/16" PUNCH FLUSH WITH FRAME.
- ENSURE YOUR SIGHT HAS FUNCTIONAL ADJUSTMENT AFTER ASSEMBLY.