

# Installation Instructions for Wilson Combat® Whisper Suppressors

**Make sure your firearm is UNLOADED!!!**

Remove original flash hider/muzzle brake if necessary.

Thread suppressor brake onto barrel and check for indexing. Brake should index with the ports horizontal. If you're lucky and it does, simply tighten and you're done.



**Properly Indexed with Ports Horizontal**

If the brake doesn't index properly you will need to add shims until it does.



**NOT Properly Indexed**

Install the thick (.031") shim on the barrel and re-install brake. If brake still doesn't index properly, continue by adding thin shims until you get the desired index with the brake properly tightened.



**NOTE: It is important that you install the thick (.031") shim on the barrel first.**

The thickest and thinnest shims are uncolored silver and the colored ones vary in approximately in .001" increments.

Install heat resistant O-ring on brake.

Lightly lubricate the threads of the suppressor with a light grease or heavy weight oil (we recommend Ultima-Lube II Universal or Grease). Install suppressor on brake and you're ready to shoot.



Note: If you plan to leave the brake on the barrel permanently we recommend the use of Loctite 271 (red) threadlocker.