SHOWERWALL DATA SHEET



Details of our Laminate range.

LAMINATE PANELS - The Original, Impression and Majestic Collections

	DIMENSIONS	EXTERIOR GRADE MDF COREBOARD WEIGHT	PLYWOOD COREBOARD WEIGHT
Square Cut Panels	2440 x 900 x 10.5mm	20kg	15kg
	2440 x 1200x 10.5mm	27kg	20kg
Proclick Panels	2440 x 579x 10.5mm	13kg	11kg
	2440 x 879x 10.5mm	20kg	15kg
	2440 x 1179x 10.5mm	27kg	20kg

DIMENSION TOLERANCES

Width	+/- 3.0mm
Height	+/- 5.0mm
Thickness	+/- 0.5mm
Flatness	≤ 3 mm/m
Squareness	+/- 1.5mm per 1000mm

MATERIAL

A range of 40+ decor types are available. Face laminates are produced to EN 438 standard (VGS) and are bonded to a quality exterior grade MDF, or Plywood using a D3 adhesive applied under strictly controlled conditions. A balancing backing laminate is then bonded to the panel reverse.

Showerwall exterior-grade MDF coreboard is manufactured to the EN 622-5 standard, while the plywood coreboard is made according to the EN 314-2 Class 3 and EN 636 standards.

FIRE RATINGS / PERFORMANCE

All Showerwall panels are classified EN 13501. In addition, selected decors are British Standard Fire Rated Class 2-BS 476: Part 7: 1997. Please check with your Showerwall supplier or retailer for confirmation of any particular decors F.R status prior to purchase, if required.

DISCLAIMER

Be aware that gloss finished decors have a lower scratch resistance than textured decors and that the stated care & maintenance procedures must be followed to minimise normal wear and tear of the products.

GUARANTEE

30 year warranty against manufacturing defects in a domestic environment (subject to installation registration), and 5 years when installed in a commercial environment.

CARE & MAINTENANCE

Do

- Regularly use Showerwall cleaner to clean the panels. This contains an anti-bacterial agent.
- Replace any exposed silicone sealant periodically, or as necessary, to ensure a continual waterproof seal. Showerwall silicone remover is available to assist with this procedure.
- Rinse your Showerwall panels down after use as a multitude of various chemicals can be present within personal hygiene products used in bathrooms. Rinsing these off, avoids issues such as sealant discolouration.
- Ensure adequate ventilation is present when using your shower or bath to avoid mould and mildew growth occurring.

Don't

- Use any form of abrasive cleaner as these may result in dulling of your panel surface and accelerated wear affects.
- Use any form of bleach product to clean your Showerwall panels as harsh chemicals contained in bleaches can affect the surface of your panel and sealant.

WWW.SHOWERWALL.CO.UK