

## Foam Board

## Hollow Out

Drill 1/8" or larger—  
for blind nuts.

Drill 3/16" Dia

1/8" plywood

## 3M blind nuts, 9mm Dia

Hollow O

10

1

Hollow