



Mark and crease with wing spars in place

Mark and crease with wing spars in place

Wing Construction Brace

1/8" Plywood Spar
Foam Spar

Foam Spar
Foam Spar

1/6" Hobby Plywood Joiner

1/8" Plywood Spar
Foam Spar

Foam Spar
Foam Spar

Bottom Sheet

Bottom Sheet

Canopy

Canopy

28 x 30 Power Pod

Air Vent

Air Vent