

— Cut Line  
- - - 50% Cut Line  
- - - Crease Line

10 20 30 40 50 60 70 80 90 100mm

1 2 3 4 5 6 inches

**Morane-Saulnier M.S.406**  
Design By : Vincent Unrau  
RCFBAirCraft  
Email : unrauvgmail.com

— Cut Line  
- - - 50% Cut Line  
- - - Crease Line

Remove after wing placement

Remove after wing placement

Turnigy D2836/8 Power Pod

Remove after wing placement

Remove after wing placement

Bottom Sheet

Bottom Sheet

Bottom Sheet

1/16" Hobby Plywood Joiner

foam Joiner

foam Joiner

Wing Construction Prop

Canopy

Canopy

B-1

B-1

B-2

B-2

B-2a

B-2a

B-10

B-10

B-3

B-4

B-9

B-11

B-11

B-11

B-11

B-11

B-5

B-6

B-7

B-8

B-5

B-6

B-7

B-8

1/8" Plywood Spar

1/8" Plywood Spar

Foam Spar

Foam Spar

Foam Spar

Foam Spar

Foam Spar

Foam Spar

Turnigy D2836/8 Power Pod

Build Helpers

Build Helpers

Build Helpers